

# **Bangladesh Power Development Board**

INTEGRATED MANAGEMENT SYSTEM (BASED ON ISO 9001:2015, ISO 14001:2015 & ISO 45001:2018 STANDARDS)

PROCEDURE FOR OPERATION & CONTROL OF AUXILIARY SYSTEMS – HIGH SPEED DIESEL



Document No.: BPDB-IMS-PR-019

Revision No.: 00

Effective Date: 01-11-2021

Page 2 of 7

# PROCEDURE FOR OPERATION & CONTROL OF AUXILIARY SYSTEMS – HIGH SPEED DIESEL

# 1.0 Purpose

- To determine and plan its processes and define the functions that are necessary for providing generation of electric power that can continue to meet the needs and expectations of customers
- b. To plan and control in accordance with the organizations strategy
- c. To run the processes under controlled condones
- d. To monitor, measure and review activities.
- e. To ensure a method for safe and review activities

## 2.0 Scope

Applies to Integrated Management system of high speed diesel power plant of Bangladesh Power Development Board (BPDB)

#### 3.0 Terms & Definition

#### **Definition**

#### **Abbreviations**

BPDB – Bangladesh Power Development Board MR – Management Representative

### 4.0 Roles and Responsibility

Tasks in Reference Clause nos.	Responsibility
5.0	Directorate of Program & Project's
	officials
5.1, 5.2, 5.3, 5.5	MMD/Ope
5.4	I & CD/Ope

#### 5.0 Procedure

Auxiliary processes consist of followings

- a) Lubricating oil system
- d) Hydraulic Ratchet System
- b) Water cooling system
- e) Fuel System
- c) Hydraulic oil system

#### 5.1 Lubricating oil system:

- The lubricating oil system maintains the quality of the bearing lubricating oil.
   The system provide) the necessary cooling to prevent overheating of the bearing.
- Lubricating oil system consists of three pumps.

Prepared By	Assessed B	
Reviewed By	Approved By	



Document No.: BPDB-IMS-PR-019

Revision No.: 00

Effective Date: 01-11-2021

Page **3** of **7** 

# PROCEDURE FOR OPERATION & CONTROL OF AUXILIARY SYSTEMS – HIGH SPEED DIESEL

- 1. Auxiliary lube oil pump (AC); operate automatically during the cool down operation only if the lube oil pressure fall down during the units at running condition it is run automatically, I
- 2. Main lube oil pump (Gear driven pump); Operate during the running condition only by the power of turbine shaft with the help of an auxiliary gear.
- 3. Emergency lube oil pump (DC), if the auxiliary power is failed by any cause and the auxiliary lube oil pump stopped then it will be run automatically.

### 5.2 Water cooling system:

 The water cooling system removes heat from lube oil by circulating cool water through heat exchanger. After absorbing heat from lube oil; heated water circulated through the radiator and cool down by air it consists of water circulation pump (Gear driven), radiator and Cooling fan. I Demi water is used for cooling with a close cycle I and operates automatically

### 5.3 Hydraulic oil system:

 Hydraulic oil system maintain the desire oil i pressure to operate and control Inlet guide van (IGV) and trip circuit. It consists of auxiliary pump (AC) and main pump (Gear driven). Gear driven pump operate automatically by the power of turbine shaft with the help of an auxiliary gear

# 5.4 Hydraulic Ratchet system:

- Hydraulic Ratchet system function is to rotate the turbine rotor during start-up, cool down and when needed during a maintenance inspection during start-up, it is used as a breakaway device to reduce the power requirements of starting device.
- During cool down, the hydraulic ratchet system turns the turbine/generator rotor at specified cycles to prevent bowing of the turbine rotor to protect the turbine rotor and the unit bearings from thermal damage.
- It consists of an electrical motor which is automatically engaged with turbine shaft after shut dawn/stopped/tripped the unit and disengaged after starting the unit by the help of starting clutch. This system consist a DC motor to provide turning operation.

#### 5.5 Fuel system:

 Fuel system provides required quantity of fuel (HSD) with desired pressure to the turbine I combustion chamber from Fuel forwarding skid. I The fuel pump is driven by accessory gear

# 5.6 Environmental Aspect, Impact & Controls

Prepared By		
Reviewed By	Approved By	



Document No.: BPDB-IMS-PR-019

Revision No.: 00

Effective Date: 01-11-2021

Page **4** of **7** 

# PROCEDURE FOR OPERATION & CONTROL OF AUXILIARY SYSTEMS – HIGH SPEED DIESEL

Any activity at the plant, whether it is carried out for ensuring quality of service or meeting requirement of the interested parties, there will be some environmental aspects associated with it. It is a requirement of the IMS of BPDB to identify those environmental aspects, evaluate their impact and determine necessary controls. While carrying out the activities and operation, the employees of BPDB need to exercise appropriate and predetermined controls so as to prevent or mitigate any adverse impact that may be associated with the activity or the process.

Some examples of environmental aspects associated with the procedure for Operation & Control of Auxiliary Systems-High Speed Diesel are as below:

SI Nos.	Aspect	Impact	Controls
1.	Electricity Consumption	Global Warming	Ensure Components are running efficiently
2.	Use of lubricant	Soil Pollution	Follow the waste management plan     Work and dispose as per the chemical disposal plan
3.	Oil Leakage	Soil Pollution	Regular Inspection and monitoring
4.	Water Use for Cooling	Water Use	Ensure that therer is no leakage for water delivery
5.	Paper Use	Natural resource depletion	1. Reuse of Paper with the blank side
6.	Recruitment of incompetent people	Inadequate knowledge on operation and environmental management may lead to unnecessary environmental pollution	1. Awareness training given periodically to relevant staffs on environmental management issues 2. On-job training related to environmental awareness given to staffs and workers.

The table above provides examples only. The IMS team of each site needs to identify the aspect impact and controls related to specific activities and ensures that the environmental performance of the organization is effectively maintained. For this purpose, the procedure "Environmental Aspect Impact Assessment Procedure" is to

Prepared By	A I D	
Reviewed By	Approved By	



Document No.: BPDB-IMS-PR-019

Revision No.: 00

Effective Date: 01-11-2021

Page **5** of **7** 

# PROCEDURE FOR OPERATION & CONTROL OF AUXILIARY SYSTEMS – HIGH SPEED DIESEL

be followed and forms "Environmental Aspect Impact Register" is to be filled up by the IMS team.

### 5.7 OHS Hazard, Risk & Controls

Any activity at the plant, whether it is carried out for ensuring quality of service or meeting requirement of the interested parties, there will be some occupational hazards with it related to the occupational health and safety (OHS) to the workers and employees. It is a requirement of the IMS of BPDB to identify those OHS hazards and determine necessary controls.

While carrying out the activities and operation, the employees of BPDB need to exercise appropriate and predetermined controls so as to prevent or mitigate any adverse consequence that may be associated with the activity or the process.

Some examples of OHS hazards and with the procedure for Operation & Control of Auxiliary Systems-High Speed Diesel are as below:

SI Nos.	OHS Hazard	Controls		
1.	High Noise Level	Staff must wear Earmuff whilst in the Engine room		
2.	Slipping due to water spillage on floors	<ol> <li>Maintain adequate housekeeping.</li> <li>Maintain signage if there is any spill.</li> </ol>		
3.	dropping / falling object	Maintain adequate PPE (e.g. Helmet)     whilst at worksite		
4.	Electric shock / Electric Arc	Ensure a Permit to Work is issued as per guidance before personnel is sent for work     Maintain LoTo Procedure     Maintain adequate PPE whilst at worksite		
5.	Fire / Explosion at worksite	Follow the 'Prevention of Fire and Explosion' Procedure		
6.	Heat Stress	<ol> <li>Ensure Heat Stress Training for all the employees</li> <li>Ensure a good work plan</li> </ol>		
7.	Getting Stuck in moving / Rotating Parts	<ol> <li>Ensure protocols are maintained, such as not leave loose long hair, or loose long dress</li> <li>Proper signage</li> <li>Maintain barrier / mark area so that when personnel enter that zone, he/she is obliged to take adequate precautions</li> </ol>		
8.	Chemical Spillage / Burn	Provide Necessary Training     Maintain adequate PPE whilst at		

Prepared By	A 1 B	
Reviewed By	Approved By	



Document No.: BPDB-IMS-PR-019

Revision No.: 00

Effective Date: 01-11-2021

Page **6** of **7** 

# PROCEDURE FOR OPERATION & CONTROL OF AUXILIARY SYSTEMS – HIGH SPEED DIESEL

	-	•
		worksite
		3. Ensure good House Keeping
9.		Use of Guards to ensure contact can't
	Burn from contact with hot	be made directly
	surface	2. Provide Caution Sign
	Surface	Maintain adequate PPE whilst at
		worksite
10.		Maintain adequate PPE whilst at
		worksite
	Fumes and gases	2. Ensure a Permit to Work is issued as
		per guidance before personnel is sent for
44		work
11.		Provide Necessary Training     Maintain and sweets RRF whilet at
	Light from welding	Maintain adequate PPE whilst at worksite
		3. Proper Supervision
12.	Unhygienic work environment	3. FTopel Supervision
12.	e.g. canteen, toilet etc.	Maintain adequate housekeeping.
13.	c.g. carriceri, tolici cic.	Maintain Material handling Procedure
	Cuts from Material Handling /	2. Ensure a Permit to Work is issued as
	movement	per guidance before personnel is sent for
		work
14.	Poor Visibility due to improper	Maintain adequate housekeeping.
	lighting	2. Installing adequate Lighting
15.		Maintain Material handling Procedure
	Lifting heavy objects	2. Ensure a Permit to Work is issued as
	Liming floavy objects	per guidance before personnel is sent for
40	1	work
16.	Dusty environment	Ensure adequate housekeeping
17.	Leaking Gas Supply Pipeline	Check LEL detector Status
18.	Possibility of flamable	1. Follow the 'Prevention of Fire and
	gases/fumes in engine room	Explosion' Procedure
	chamber	·
19.		Regular Inspection and maintenance
	Fire on transformer	2. Follow the 'Prevention of Fire and
		Explosion' Procedure
20.	Coolant Bio a Leaf and	Inspect and Monitor condition of Pipe
	Coolant Pipe Leakage	Regularly
		2. Take corrective action immediatey

The table above provides examples only. The IMS team of each site needs to identify the OHS hazards and necessary controls related to specific activities and ensures that the environmental performance of the organization is effectively maintained. For this, the procedure Hazard Identification and Risk Assessment

Prepared By	A I D	
Reviewed By	Approved By	



Document No.: BPDB-IMS-PR-019

Revision No.: 00

Effective Date: 01-11-2021

Page **7** of **7** 

# PROCEDURE FOR OPERATION & CONTROL OF AUXILIARY SYSTEMS – HIGH SPEED DIESEL

Procedure is to be followed and Hazard Identification and Risk Assessment Register is to be filled up by the IMS team.

6.0 Reference	es
---------------	----

None

# 7.0 Appendix

None

# 8.0 Revision History

SI No.	Revision Number	Section	Change Made	Date of Revision

Prepared By	Approved Dy	
Reviewed By	Approved By	